

To select another type of nut, select the appropriate nut type and the table will display below:

| | | | | | | | |
|---|---|--|--|----------------------------------|-----------------------------------|----------------------------------|---|
| <input checked="" type="radio"/> KM series | <input type="radio"/> KML series | <input type="radio"/> HM T series | <input type="radio"/> HM series | <input type="radio"/> KMK | <input type="radio"/> KMFE | <input type="radio"/> KMT | <input type="radio"/> DIN 1804 (M) |
|---|---|--|--|----------------------------------|-----------------------------------|----------------------------------|---|

| Nuts | | Spanners | | | | | |
|--------------------|----------------------|-----------|------------|---------------|--------------|--------|-------------|
| D outside nut (mm) | KM series | HN series | HNA series | HN SNL series | TMFN series | TMHN 7 | TMFS series |
| 16 | | HN 0 | | | | | |
| 18 | KM 0 | HN 0 | | | | | TMFS 0 |
| 20 | | HN 0 | HNA 1-4 | | | | |
| 22 | KM 1 | HN 1 | HNA 1-4 | | | | TMFS 1 |
| 25 | KM 2 | HN 2-3 | HNA 1-4 | | | | TMFS 2 |
| 28 | KM 3 | HN 2-3 | HNA 1-4 | | | | TMFS 3 |
| 30 | | HN 4 | HNA 1-4 | | | | |
| 32 | KM 4 | HN 4 | HNA 1-4 | | | | TMFS 4 |
| 33 | | HN 4 | HNA 1-4 | | | | |
| 34 | | | HNA 1-4 | | | | |
| 36 | | | HNA 5-8 | | | | |
| 37 | | HN 5-6 | HNA 5-8 | | | | |
| 38 | KM 5 | HN 5-6 | HNA 5-8 | HN 5/SNL | | HNM 5 | TMFS 5 |
| 40 - 44 | | HN 5-6 | HNA 5-8 | | | | |
| 45 | KM 6 | HN 5-6 | HNA 5-8 | HN 6/SNL | | HNM 6 | TMFS 6 |
| 49 - 50 | | HN 7 | HNA 5-8 | | | | |
| 52 | KM 7 | HN 7 | HNA 5-8 | HN 7/SNL | | HNM 7 | TMFS 7 |
| 54 - 55 | | HN 7 | HNA 5-8 | | | | |
| 58 | KM 8 | HN 8-9 | HNA 5-8 | HN 8/SNL | | HNM 8 | TMFS 8 |
| 62 | | HN 8-9 | HNA 9-13 | | | | |
| 65 | KM 9 | HN 8-9 | HNA 9-13 | HN 9/SNL | | HNM 9 | TMFS 9 |
| 68 | | HN 10-11 | HNA 9-13 | | | | |
| 70 | KM 10 | HN 10-11 | HNA 9-13 | HN 10/SNL | | HNM 10 | TMFS 10 |
| 75 | KM 11 | HN 10-11 | HNA 9-13 | HN 11/SNL | | HNM 11 | TMFS 11 |
| 80 | KM 12 | HN 12-13 | HNA 9-13 | HN 12/SNL | | | TMFS 12 |
| 85 | KM 13 | HN 12-13 | HNA 9-13 | HN 13/SNL | | | TMFS 13 |
| 90 | | HN 12-13 | HNA 9-13 | | | | |
| 92 | KM 14 | HN 14 | HNA 14-24 | | | | TMFS 14 |
| 95 | | HN 15 | HNA 14-24 | | | | |
| 98 | KM 15 | HN 15 | HNA 14-24 | HN 15/SNL | | | TMFS 15 |
| 100 | | HN 15 | HNA 14-24 | | | | |
| 105 | KM 16 | HN 16 | HNA 14-24 | HN 16/SNL | | | TMFS 16 |
| 110 | KM 17 | HN 17 | HNA 14-24 | HN 17/SNL | | | TMFS 17 |
| 115 | | HN 18-20 | HNA 14-24 | | | | |
| 120 | KM 18 | HN 18-20 | HNA 14-24 | HN 18/SNL | | | TMFS 18 |
| 125 | KM 19 | HN 18-20 | HNA 14-24 | HN 19/SNL | | | TMFS 19 |
| 130 | KM 20 | HN 18-20 | HNA 14-24 | HN 20/SNL | | | TMFS 20 |
| 135 | | HN 21-22 | HNA 14-24 | | | | |
| 140 | KM 21 | HN 21-22 | HNA 14-24 | | | | |
| 145 | KM 22 | HN 21-22 | HNA 14-24 | HN 22/SNL | | | |
| 150 | KM 23 | | HNA 14-24 | | TMFN 23-30 | | |
| 155 | KM 24 | | HNA 14-24 | HN 24/SNL | TMFN 23-30 | | |
| 160 - 195 | KM 25 - KM 30 | | | | TMFN 23-30 | | |
| 200 - 250 | KM 31 - KM 40 | | | | TMFN 30-40 | | |
| 260 - 320 | | | | | TMFN 40-52 | | |
| 290 - 400 | | | | | TMFN 52-64 | | |
| 420 - 520 | | | | | TMFN 64-80 | | |
| 540 - 620 | | | | | TMFN 80-500 | | |
| 630 - 730 | | | | | TMFN 500-600 | | |
| 750 - 950 | | | | | TMFN 600-750 | | |

